

**TERA TR-505-GMAX “GMRS, MURS & NOAA WX with VOX & PWR”
7 GM/FRS, 2 GMRS, 1 GMRS RPT, 5 MURS, 1 NOAA ‘All Hazards’ NWS WX
Customer-Submitted Programming Chart
Not FCC Part 95E or J Compliant**

Channel	Description	Rx Freq	Rx PL	Tx Freq	Tx PL	Mode	Power	Scan
1	GM/FRS 1 Simplex CALL	462.5625		462.5625	88.5	N	4W	✓
2	GM/FRS 2 Simplex SAFETY	462.5875		462.5875	88.5	N	4W	✓
3	GM/FRS 3 Simplex EM	462.6125		462.6125	88.5	N	4W	✓
4	GM/FRS 4 Simplex	462.6375		462.6375	88.5	N	4W	✓
5	GM/FRS 5 Simplex	462.6625		462.6625	88.5	N	4W	✓
6	GM/FRS 6 Simplex	462.6875		462.6875	88.5	N	4W	✓
7	GM/FRS 7 Simplex	462.7125		462.7125	88.5	N	4W	✓
8	GMRS 17 Simplex EM	462.6000		462.6000	88.5	W	4W	✓
9	GMRS 20 Simplex EM TRV	462.6750		462.6750	141.3	W	4W	✓
10	GMRS 20 Repeater EM TRV	462.6750		467.6750	141.3	W	4W	
11	MURS 1 Simplex CALL	151.8200		151.8200	88.5	W	2W	✓
12	MURS 2 Simplex SAFETY	151.8800		151.8800	88.5	W	2W	✓
13	MURS 3 Simplex EM	151.9400		151.9400	88.5	W	2W	✓
14	MURS 4 Simplex BLUE DOT	154.5700		154.5700	88.5	W	2W	✓
15	MURS 5 Simplex GREEN DOT	154.6000		154.6000	88.5	W	2W	✓
16	WX 1 M39B NOAA/NWS Rx	162.5500				W		

Side Key Assignments

Mid - Short Press	Scan Mode (On/Off)
Mid - Long Press	Channel Lock (On/Off)
Low - Short Press	Tx Power (Hi/Low)
Low - Long Press	VOX Mode (On/Off)