

**TERA TR-505-GFRS “GM/FRS, GMRS TRV & NOAA WX”
 14 GM/FRS, 1 GMRS Emergency/Travel, 1 NOAA ‘All Hazards’ NWS WX
 Customer-Submitted Programming Chart
 Not FCC Part 95B or E Compliant**

Channel	Description	Rx Freq	Rx PL	Tx Freq	Tx PL	Mode	Power	Scan
1	GM/FRS 1 Simplex CALL	462.5625		462.5625	88.5	N	4W	✓
2	GM/FRS 2 Simplex SAFETY	462.5875		462.5875	88.5	N	4W	✓
3	GM/FRS 3 Simplex EM	462.6125		462.6125	88.5	N	4W	✓
4	GM/FRS 4 Simplex	462.6375		462.6375	88.5	N	4W	✓
5	GM/FRS 5 Simplex	462.6625		462.6625	88.5	N	4W	✓
6	GM/FRS 6 Simplex	462.6875		462.6875	88.5	N	4W	✓
7	GM/FRS 7 Simplex	462.7125		462.7125	88.5	N	4W	✓
8	GM/FRS 8 Simplex	467.5625		467.5625	88.5	N	4W	✓
9	GM/FRS 9 Simplex	467.5875		467.5875	88.5	N	4W	✓
10	GM/FRS 10 Simplex	467.6125		467.6125	88.5	N	4W	✓
11	GM/FRS 11 Simplex	467.6375		467.6375	88.5	N	4W	✓
12	GM/FRS 12 Simplex	467.6625		467.6625	88.5	N	4W	✓
13	GM/FRS 13 Simplex	467.6875		467.6875	88.5	N	4W	✓
14	GM/FRS 14 Simplex	467.7125		467.7125	88.5	N	4W	✓
15	GMRS 20 Simplex EM TRV	462.6750		462.6750	141.3	W	4W	✓
16	WX 1 M39B NOAA/NWS Rx	162.5500				W		

Side Key Assignments

Mid - Short Press	Scan Mode (On/Off)
Mid - Long Press	Channel Lock (On/Off)
Low - Short Press	Tx Power (Hi/Low)
Low - Long Press	Monitor (Momentarily Open Squelch)